Arduino Programming Part II

ME 120

Mechanical and Materials Engineering Portland State University http://web.cecs.pdx.edu/~me120

Overview

Review of Blink Variable Declarations Variable Assignments Built-in I/O functions

See on-line reference:

http://arduino.cc/en/Reference/HomePage

Blink code



Declare **led** and assign a value

Built-in functions: pinMode digitalWrite delay

Variables in Arduino programs

Using Variables and Functions

Assigning values to a variable: "int" is a type of variable int led = 12;

pinMode and digitalWrite expect "int" variables as inputs
 pinMode (led,OUTPUT) ;
 digitalWrite (led,HIGH) ;

OUTPUT and HIGH are pre-defined constants See http://arduino.cc/en/Reference/Constants

Variable types

Three basic categories of variables

- integers
- floating point values
- character strings

Integers

- ✤ No fractional part. Examples: 1, 2, 23, 0, -50213
- Used for counting and return values from some built-in functions
- Integer arithmetic results in truncation to integers

Floating point numbers

- ✤ Non-zero fractional parts. Examples 1.234, –2.728, 4.329 x 10⁻⁴
- Large range of magnitudes
- Floating point arithmetic does not truncate, but has round-off

Integer types

int integer in the range -32,768 to 32,767
long integer in the range -2,147,483,648 to 2,147,483,647
unsigned int positive integer in the range 0 to 65,535
unsigned long positive integer in the range 0 to 4,294,967,295



ME 120: Arduino Programming

Floating point types

- float values with approximately seven significant digits in the range $\pm(1.80 \times 10^{-38} \text{ to } 3.40 \times 10^{38})$
- double values with approximately thirteen significant digits in the range $\pm (2.2 \times 10^{-308} \text{ to } 1.80 \times 10^{308})$

There is no double on an Arduino Uno. On an Uno, a double is the same as a float.

Declaring and assigning values

Declarations are necessary. Assignments are optional

```
int n; // single declaration
int i,j,k,n; // multiple declaration
int i=5; // single declaration and assignment
int i=5, j=2; // multiple declaration and assignment
float x;
float x,y,z;
float x=0.0, y=-1.23e5; // assignment with "e" notation
```

Notes

- Integer values do not use decimal points
- Floating point values can use "e" notation
 - ▶ 1.23e5 is equal to 1.23 x 10⁵
 - DO NOT write x = 1.23*10^5 instead of x = 1.23e5

See http://arduino.cc/en/Reference/Float and http://arduino.cc/en/Reference/Double

Assigning values

The equals sign is the assignment operator

- The statement x = 3 assigns a value of 3 to x. The actual operation involves storing the value 3 in the memory location that is reserved for x.
- The equals sign does not mean that x and 3 are the same!
- ♦ Symbolically you can replace x = 3 with $x \leftarrow 3$.

Consider the following sequence of statements

```
x = 3;
y = x;
x = 5;
```

The preceding statements are executed in sequence. The last assignment determines the value stored in x. There is no ambiguity in two "x =" statements. The x = 5; statement replaces the 3 stored in x with a new value, 5.

Test your understanding

What are the values of n and z at the end of the following sequences of statements?

<pre>int i,j,k,n; i = 2; j = 3; k = i + 2*j; n = k - 5;</pre>	<pre>int i,j,k,n; i = 2; j = 3; n = j - i; n = n + 2;</pre>	<pre>int n; float x,y,z; x = 2.0; y = 3.0; z = y/x; n = z;</pre>
n = ?	n = ?	z = ? n = ?

Test your understanding

What are the values of n and z at the end of the following sequences of statements?

int i,j,k,n;	<pre>int i,j,k,n;</pre>	<pre>int n; float x,y,</pre>	z ;
i = 2;	i = 2;		
j = 3;	j = 3;	x = 2.0;	
k = i + 2*j;	n = j - i;	y = 3.0;	
$\mathbf{n} = \mathbf{k} - 5;$	n = n + 2;	z = y/x;	
		n = z;	

The n = n + 2; statement shows why it is helpful to think of the equal sign as a left facing arrow.

You can mentally replace n = n + 2; with $n \leftarrow n + 2$;

We have to be aware of the rules of numerical computation used by Arduino hardware (and computers, in general).

Integer arithmetic always produces integers

```
int i,j;
i = (2/3)*4;
j = i + 2;
```

What values are stored in i and j?

We have to be aware of the rules of numerical computation used by Arduino hardware (and computers, in general).

Integer arithmetic always produces integers

```
int i,j;
i = (2/3)*4;
j = i + 2;
```

What values are stored in i and j?

Answer: $i \leftarrow 0$, $j \leftarrow 2$

Integer arithmetic always produces integers

int i,j; i = (2.0/3.0)*4.0; j = i + 2;

What values are stored in i and j?

Answer: $i \leftarrow 2$, $j \leftarrow 4$

Floating point arithmetic preserves the fractional part of numbers, but it does so approximately

float w,x,y,z; w = 3.0; x = 2.0; y = w/x; z = y - 1.5;

What values are stored in y and z?

Floating point arithmetic preserves the fractional part of numbers, but it does so approximately

float w,x,y,z; w = 3.0; x = 2.0; y = w/x; z = y - 1.5;

What values are stored in y and z?

Answer: $y \leftarrow 1.5$, $z \leftarrow 0$

Consider this alternate test*

float w,x,y,z; w = 4.0/3.0; x = w - 1; y = 3*x; z = 1 - y;

*See, e.g. C. Moler, *Numerical Computing in MATLAB*, 2004, SIAM, p. 38

Consider this alternate test*

```
float w,x,y,z;
w = 4.0/3.0;
x = w - 1;
y = 3*x;
z = 1 - y;
```

which produces x = 0.333 and y = 1.000 and z = -1.19e-7

*See, e.g. C. Moler, *Numerical Computing in MATLAB*, 2004, SIAM, p. 38

Global and local variables

```
In this sketch, LED_pin is a global
variable, accessible to other functions in
the file
int LED_pin = 13;
void setup() {
    pinMode( LED_pin, OUTPUT );
}
void loop() {
    digitalWrite( LED_pin, HIGH );
    delay(1000);
    digitalWrite( LED_pin, LOW );
    delay(1000);
}
```

In this sketch, **LED_pin** is a local variable in the setup function, and is not accessible to the code in the loop function. *This sketch will not compile. It cannot be run.*

```
void setup() {
    int LED_pin = 13;
    pinMode( LED_pin, OUTPUT );
}
```

```
void loop() {
   digitalWrite( LED_pin, HIGH );
   delay(1000);
   digitalWrite( LED_pin, LOW );
   delay(1000);
}
```

In general, it is wise to avoid global variables unless you must. Since LED_pin must be accessible to setup and loop, it has to be a global variable.

Built-in Arduino functions

All sketches have setup() and loop()

void setup()

- Executed only once
- No input arguments: parentheses are empty
- No return values: function type is void

void loop()

- Executed repeatedly
- No input arguments: parenthesis are empty
- No return values: function type is void

Digital input and output (1)

Digital I/O pins 0 through 13 can respond to input or be sources of output

pinMode(pin, mode)

- Configures a digital I/O pin for input or output
- ✤ pin specifyies the digital I/0 channel: 0 to 13
- mode one of: INPUT, OUTPUT or INPUT_PULLUP
 - we use OUTPUT to set the pin as a power source for an LED
 - we use INPUT when we read a digital input, such as a button
- No return value: function type is void

Digital input and output (2)

digitalWrite(pin,value)

- ✤ Sets the state of a digital I/O pin
- ✤ pin specifies the digital I/0 channel: 0 to 13
- value one of: HIGH or LOW
- No return value: function type is void

digitalRead(pin)

- ✤ Reads the state of a digital I/O pin
- ✤ pin specifies the digital I/0 channel: 0 to 13
- Returns and int that is equivalent to either LOW or HIGH

Analog input

analogRead(pin)

- Reads the voltage on an analog input pin
- pin an integer that specifies the analog input channel: 0 to 5.
 pin can also be referred to by name as A0, A1, A2, A3, A4 or A5
- Returns an int in the range 0 to 1023 (for an Arduino Uno)

Example: Read a potentiometer



ME 120: Arduino Programming

Serial communication with host computer (1)

Serial.begin(speed)

Initializes the Serial port at speed. Typical speed is 9600

Serial.print(value)

- Sends value to the serial port
- value can be a single number or a character string
- No newline after value is sent

Serial.println(value)

- Sends value to the serial port
- value can be a single number or a character string
- Add a newline after value is sent

Serial communication with host computer (2)

Example: Read two analog channels and print values

```
void setup() {
 Serial.begin(9600); // Initialize serial port object
}
void loop() {
 int value1,value2;
 float now;
 now = millis()/1000.0; // Current time in seconds
 value1 = analogRead(A0); // Read analog input channel 0
 value2 = analogRead(A1);
                         // and channel 1
 Serial.print(now); // Print the time
 Serial.print(" "); // Make a horizontal space
 Serial.print(value1); // Print the first reading
 Serial.print(" "); // Make another horizontal space
 Serial.println(value2); // Print second reading & newline
}
```

Codes to demonstrate integer and floating point arithmetic

```
11
    File: int test.ino
11
// Demonstrate truncation with integer arithmetic
11
    ME 120, Lecture 5, Fall 2013
void setup() {
  int i,j;
  Serial.begin(9600);
 delay(3500);
                   // wait for user to open the serial monitor
 // -- First example: slide #13
 i = (2/3) * 4;
  j = i + 2;
  Serial.println("First test");
  Serial.print(i); Serial.print(" "); Serial.println(j);
 // -- Second example: slide #15
  i = (2.0/3.0) * 4.0;
 j = i + 2;
  Serial.println("Second test");
  Serial.print(i); Serial.print(" "); Serial.println(j);
}
void loop() {} // Loop does nothing. Code in setup() is executed only once
```

Floating point arithmetic: test 1

```
11
    File: float test.ino
11
11
    Demonstrate floating point arithmetic computations that happen to
    have no obvious rounding errors. That DOES NOT always happen
11
11
11
    Use two-parameter form of Serial.print. The second parameter specifies
11
    the number of digits in value sent to the Serial Monitor
void setup() {
  float w,x,y,z;
 Serial.begin(9600);
 delay(2500);
                        // wait for user to open the serial monitor
 // -- Computations that return results that you would expect; No rounding
 w = 3.0;
 x = 2.0;
 y = w/x;
  z = v - 1.5;
 Serial.println("Floating point arithmetic test");
 Serial.print(w,8); Serial.print("
                                      ");
 Serial.print(x,8); Serial.print("
                                      ");
 Serial.print(y,8); Serial.print("
                                      ");
 Serial.print(z,8); Serial.print(" ");
 Serial.println(z*1.0e7,8);
}
```

void loop() {} // Loop does nothing. Code in setup() is executed only once

Floating point arithmetic: test 2

```
11
    File: float test 2.ino
11
11
    Demonstrate well-known round-off error problem with floating point arithmetic
11
     See, e.g., Cleve Moler, Numerical Computing in MATLAB, p. 38
11
11
     Use two-parameter form of Serial.print. The second parameter specifies
11
     the number of digits in value sent to the Serial Monitor
void setup() {
  float w,x,y,z;
  Serial.begin(9600);
  delay(2500);
                        // wait for user to open the serial monitor
 // -- Computations that show rounding
 w = 4.0/3.0;
 x = w - 1;
 y = 3 * x;
  z = 1 - y;
  Serial.println("\nFloating point arithmetic test 2");
  Serial.print(w,8); Serial.print("
                                      ");
  Serial.print(x,8); Serial.print("
                                      ");
  Serial.print(y,8); Serial.print("
                                      ");
  Serial.print(z,8); Serial.print(" ");
  Serial.println(z*1.0e7,8);
}
void loop() {} // Loop does nothing. Code in setup() is executed only once
```