





# Pump Performance Testing




ME 199A


# Experimental Setup



12 VDC power supply




Fill Water Reservoir Bucket to the Zero Inch Mark  
(top of the PVC fitting above the outlet)





# Zero the Digital Balance

The displayed weight is the actual weight of the water




## Collect a Data Point



# Record the Data Point


height above water in supply bucket (in)	I to pump (amps)	V across pump leads (volts)	mass collected in 20 seconds (g)	time (s)
6				20
12				20
18				20
24				20
30	1.23	10.75	175	20
36				20
42				20





# Measurement of Power Used by Pump ( $P = VI$ )

- voltage measured ACROSS pump terminals
- current flows THROUGH multimeter



# Guidelines / Housekeeping / Safety

- You should take one set of data with increasing heights (going up) and another set of data coming down.
- Try to take data for 8 to 10 different heights (you can record less than every six inches if your pump won't pump 72 inches).
- Keep water away from all electrical equipment except the pump, and do your best to keep the pump motor dry.
- Don't handle the wall adapter or other power supply with wet hands or wet feet (or when in contact with water).
- Wipe up any water that leaks onto the floor.
- Report any problems encountered to the help desk.